




—
INSTALLATION INSTRUCTION

Parallel connection kit



OZXA32-33



OZXA32



OZXA33





Contact us

ABB Oy

Muottitie 2A 65320

Vaasa, Finland

abb.com/lowvoltage