

- > Port size: G1/8 & G1/4
- > Very compact unit
- > Universal useable





Technical features

Medium:

Compressed air only **Maximum inlet pressure:**20 bar (290 psi)

Pressure range:

0,3 ... 7 bar (4 ... 101 psi), 0,3 ... 3,5 bar (4 ... 50 psi), 0,1 ... 0,7 bar (1 ... 10 psi), 0,3 ... 10 bar (4 ... 145 psi)

Flow: see below Port size: G1/8 or G1/4 Rc1/8 (Gauge)

Ambient/Media temperature:

-20° ... +65°C (-4° ... +149°F) Air supply must be dry enough to avoid ice formation at temperatures below +2°C (+35°F).

Materials:


Body: Zinc alloy Bonnet and knop: Acetal Valve: Brass

Valve: Brass Seals: NBR

Technical data, standard models with relieving

Symbol	Port size	Pressure range (bar)	Flow *1) (dm³/s)	Weight (kg)	Model
<u> </u>	G1/8	0,3 7	6,5	0,19	R07-100-RNKG
	G1/4	0,3 7	7	0,19	R07-200-RNKG

 $^{^{\}star}$ 1) Flow at inlet pressure 10 bar (145 psi), outlet pressure 6,3 bar (91 psi) and pressure drop 1 bar (14 psi).




- *1) Outlet pressure can be adjusted to pressures in excess of and less than, those specified. Do not use these units to control pressures outside of the specified ranges.
- *2) When specifying 10 bar (145 psi) unit, eg. R07-205-RNMG, also note correct code at 6th digit.





Flow characteristics Port size 1/4", Pressure range 0,3 ... 7 bar



Accessories



Service kit








Dimensions


Bracket mounting


Dimensions in mm Projection/First angle











1 Panel mounting hole Ø 31 mm

Warning

These products are intended for use in industrial compressed air systems only. Do not use these products where pressures and temperatures can exceed those listed under » Technical features/data «.

Before using these products with fluids other than those specified, for non-industrial applications, life-support systems or other applications not within published specifications, consult

IMI Precision Engineering, Norgren Ltd.

Through misuse, age, or malfunction, components used in fluid power systems can fail in various modes. The system designer is warned to consider the failure modes of all component parts used in fluid power systems and to provide adequate safeguards to prevent personal injury or damage to equipment in the event of such failure.

System designers must provide a warning to end users in the system instructional manual if protection against a failure mode cannot be adequately provided.

System designers and end users are cautioned to review specific warnings found in instruction sheets packed and shipped with these products.